



COMPETITION

BEDIENUNGSANLEITUNG - NOTICE D'UTILISATION - OPERATING INSTRUCTIONS



512.5320

-  OZONGENERATOR
-  GÉNÉRATEUR D'OZONE
-  OZONE GENERATOR
-  GENERADOR DE OZONO
-  GENERATORE DI OZONO
-  OZONGENERATOR
-  GENERATOR OZONU
-  OZONGENERATOR
-  ОЗОНОВЫЙ ГЕНЕРАТОР
-  مولد الأوزون

DE/TTE/FFI/24-04-2026

KS Tools Werkzeuge und Maschinen GmbH • Seligenstädter Grund 10 –12 • 63150 Heusenstamm - GERMANY
e-mail: customerservice@competitiontools.com • www.competitiontools.com

KS Tools • PDA Région de Brumath • 1, rue de Londres • 67670 Mommenheim - FRANCE
e-mail : contact@competitiontools.com • www.competitiontools.com



Introduction

Dear Customer,

You have chosen a product from KS Tools. Thank you for your trust. This guide contains all the information you need to use the product safely and correctly. Please therefore read the instructions thoroughly before use and always follow the guidance provided. These instructions form part of the article and should therefore be kept in such a way that they remain undamaged.

If you have any queries or require further information, please contact: customerservice@competitiontools.com

1. Terms of use

The manufacturer accepts no liability for personal injury or damage to property resulting from unauthorised or improper use.



Please follow the vehicle manufacturer's instructions!

2. Technical specifications

Power supply: 230V AC

Power consumption: 65 watts

Ozone conversion: 5000 mg/h

Cable length: 1.5 m

3. Safety and Instructions for Use


Tools must generally only be used for their intended purpose, under the specified conditions and within the limits of their intended use.

- Keep children and other unauthorised persons away from the work area.
- Do not allow children to play with the product or its packaging.
- Do not use the product if any parts are missing or damaged.
- Please use the product only for its intended purpose.
- It is important that the ozone generator is properly earthed to prevent the risk of electric shock; only use cables with an earth wire!
- Replace the original fuse with a 5x20mm 2-amp glass fuse only.

Ozone is harmful to health if it is inhaled through the lungs for a prolonged period and in high concentrations. Only use this product in rooms where there are no people present.



4. Components



1	Folding handle
2	Timer / Control knob
3	Power indicator
4	Power cable connection
5	Fuse holder
6	Air filter

5. How it works

The ozone air purifier has a timer. The timer can be set for up to 120 minutes. If you turn the dial to the right (clockwise), you will activate the timer.

To leave the appliance running for a longer period, turn the rotary switch anti-clockwise to the 'ON/OFF' position. The ozone generator is intended for use only in areas where there are no people present!



Recommended operating time for different room sizes:

Recommended operating time / air volume				
10	100	150	200	300
20 mins	40 mins	60 mins	80 mins	100 mins





6. Troubleshooting

If you suspect there is a problem with the device, please check the following:

- Is the device properly plugged in and switched on?
- Is there power at the socket?
- Are the ozone plates clean, dry and free from cracks?
Clean the ozone plate about once a month. Environmental factors influence the duration of ozone release. Clean or replace the ozone plates if the ozone output is low. It is best to replace them every six months. Please contact your dealer to order a replacement.
- Is the fuse fitted correctly and in good condition?
To replace the fuse, pull out the fuse holder, remove the old fuse and replace it with a new one. The fuse is a 2-amp glass fuse measuring 5 x 20 mm.
- If the fan is not working or you cannot hear a humming sound whilst it is running, please contact your dealer.

7. Replacing / cleaning ozone plates

Disconnect the device from the mains supply (unplug the power cord from the socket and remove it from the housing), remove the housing screws, and detach the housing cover from the housing base by pulling the cover upwards. Press the release tab on the ozone plate holder and pull the ozone plates out. Clean the ozone plates with water or replace them with new ones. Make sure the plates are dry and that the metal terminals are making good contact.



8. Maintenance

Faulty or defective spare parts may cause damage.

9. Control

All tools must be checked for damage.



10. Disposal

The tool must be disposed of or recycled in accordance with the relevant national legislation.

11. Warranty and Service

The KS Tools Werkzeuge und Maschinen GmbH warranty applies to all tools used under normal operating conditions.

The following are excluded from the warranty:

- Consumables, e.g. all types of cutting tools, grinding inserts and discs, cutting and scraping tools, brooms, brushes, files, batteries, rechargeable batteries, bits or bit sockets, rotor blades in pneumatic tools, insulators on heating coils, all types of fuses, carbon brushes, etc.
- Malfunctions of parts subject to wear and tear resulting from normal use or other natural causes, as well as defects in the tool attributable to wear and tear resulting from normal use or other natural causes.
- Defects in the tool resulting from failure to follow the operating instructions, improper use, use under abnormal environmental conditions or inappropriate operating conditions, overloading or improper maintenance. This also includes defects in tools caused by the use of accessories or other parts that are not genuine KS Tools parts.
- Tools to which changes or additions have been made.
- Minor deviations from the specified quality, which are, however, of no significance to the value and serviceability of the tool.

The warranty period is 12 months in the case of commercial use or use of a similar nature. The warranty period begins on the date of purchase by the commercial end customer. The date on the original receipt is what counts. For technical products covered by a limited warranty (Types A, B and C), the user must always provide proof of purchase, stating the serial number of the device, if available.

The warranty is valid, subject to the type of warranty, for the period specified in the price list valid on the date of purchase of the product.

WARRANTY EXPLANATION

If the product is not covered by the warranty (e.g. the warranty period has expired or the warranty is excluded for the reasons listed above), but repair is possible, it will only be carried out once the user has approved the quote.

Any claims other than the right to have defects rectified, as set out in this warranty, are expressly excluded from this warranty.



COMPETITION

KS TOOLS Werkzeuge und Maschinen GmbH

Seligenstädter Grund 10 –12

63150 Heusenstamm

GERMANY

Mail: customerservice@competitiontools.com

www.competitiontools.com

KS TOOLS

PDA Région de Brumath

1, rue de Londres

67670 Mommenheim

FRANCE

Mail: contact@competitiontools.com

www.competitiontools.com

